

# Chicago Coin's Band Box®

## Reproduction Parts List

[BACK HOME](#)

Item #	Cabinet Parts Descriptions	Price EA	Quantity
1	Top Marquee	\$100.00	_____
2	Back Mural	\$100.00	_____
3	Strike Up The Band screen	\$100.00	_____
4	Hit Tune Of The Week screen	\$100.00	_____
5	Custom made lower screens	<b>CALL</b>	_____
6	Cast CC Stand set	\$225.00	_____
7	Cast CC Stand	\$50.00	_____
8	NBC Microphone	\$25.00	_____
9	Cast Horn	\$35.00	_____
10	Cast Sax	\$35.00	_____
11	Cast Violin	\$35.00	_____
12	Trombone	\$50.00	_____
13	Cast Stand Up Base	\$100.00	_____
14	Cast large Drum	\$100.00	_____
15	Large Drum Red Balls	\$20.00	_____
16	Cast Small Drum	\$45.00	_____
17	Cast Drum white cover	\$10.00	_____
18	Cabinet Side Casting set	\$275.00	_____
19	Cast Piano	\$125.00	_____
20	Drapery Arm 3 piece assy.	\$150.00	_____
21	Drapery guide rod	\$50.00	_____
22	Center guide rod support	\$5.00	_____
23	Motor shaft bracket	\$15.00	_____
24	Motor mounting bracket	\$15.00	_____
25	Motor off set bracket	\$5.00	_____
26	Standard Puppet set with Singer	\$1,300.00	_____
27	Standard Puppet set 7 piece	\$1,200.00	_____
28	Standard Singer puppet	\$200.00	_____
29	Single replacement puppet	\$200.00	_____
30	Cowboy Puppet set with Singer	<b>\$1,300.00</b>	_____
31	Cowboy Puppet set 7 piece	<b>\$1,200.00</b>	_____
32	Cowboy Singer puppet	<b>\$200.00</b>	_____
33	White Cowboy hat	<b>\$5.00</b>	_____
34	Black Cowboy hat	<b>\$5.00</b>	_____
35	<b>CUSTOM PAINTED PUPPETS</b>	<b>CALL</b>	_____
36	Base puppet support bracket	\$2.00	_____
37	Cabinet "Z" support bracket	\$3.00	_____
38	Cabinet top support rod	\$5.00	_____
39	Back door hinge	\$10.00	_____

Continued on next page

# Chicago Coin's Band Box®

## Reproduction Parts List

[BACK HOME](#)

Item #	Cabinet Parts Descriptions Cont.	Price EA	Quantity
40	Rear door latch assy.	\$35.00	_____
41	Rear door catch bracket	\$5.00	_____
42	Rear door bottom "L" bracket	\$25.00	_____
43	Top back cabinet bracket	\$15.00	_____
44	Top light valance assy.	\$15.00	_____
45	Top light valance plastic	\$5.00	_____
46	Pilaster plastic set	\$25.00	_____
47	CC stand plastic set	\$25.00	_____
48	Side castings plastic set	\$25.00	_____
49	Stage plastic set	\$50.00	_____
50	Speaker screen	\$20.00	_____
51	Cabinet trim strip set	\$200.00	_____
52	Stage trim set	\$75.00	_____
53	Drapery set	\$150.00	_____
54			_____
55			_____
56			_____
57			_____
58			_____
59			_____
60			_____
61			_____
62			_____
63			_____
64			_____
65			_____
66			_____
67			_____
68			_____
69			_____
70			_____
71			_____
72			_____
73			_____
74			_____
75			_____
76			_____
77			_____
78			_____
79			_____
80			_____
81			_____
82			_____
83			_____
84			_____

# Chicago Coin's Band Box®

## Reproduction Parts List

[BACK HOME](#)

Item #	Mech. Parts Descriptions	Price EA	Quantity
200	Complete lower mech. frame assy.	\$1,000.00	_____
201	Main mech. drive assy.	\$250.00	_____
202	3/8" hub coupling	\$20.00	_____
203	5/16" hub coupling	\$20.00	_____
204	Rubber coupling cross	\$15.00	_____
205	Small Gear Shaft Assy.	\$20.00	_____
206	Small gear	\$75.00	_____
207	Worm gear	\$50.00	_____
208	Piano cam lobe	\$50.00	_____
209	Drummer cam lobe	\$25.00	_____
210	Base cam lobe	\$15.00	_____
211	Base "L" bracket	\$2.00	_____
212	Base rod	\$1.00	_____
213	Base bow cam	\$5.00	_____
214	Violin arm rod	\$5.00	_____
215	Piano sway arm	\$25.00	_____
216	Piano sway arm bracket	\$5.00	_____
217	Piano composite wheel	\$20.00	_____
218	Drummer cam to Base head rod	\$5.00	_____
219	Violin arm to Base cam rod	\$5.00	_____
220	Trumpet / Horn player rod	\$5.00	_____
221	Gear pin to Drum. cam rod	\$5.00	_____
222	Gear pin to Cross bar rod	\$5.00	_____
223	Base spring rod assy.	\$15.00	_____
224	Base cam to Rocker arm rod	\$5.00	_____
225	Piano Head cam to Cross bar rod	\$5.00	_____
226	Base Head to Drummer cam rod	\$5.00	_____
227	Cross to Trumpet / Horn rod	\$5.00	_____
228	Base cam to Drum. cam rod	\$5.00	_____
229	Base cam to Violin cam rod	\$5.00	_____
230	Singer to Piano cam rod	\$5.00	_____
231	Violin Bow	\$5.00	_____
232	Base Bow	\$5.00	_____
233	Drummer Rod Assy.	\$5.00	_____
234	Drummer "U" Bracket	\$3.00	_____
235	Drummer composite wheel	\$20.00	_____
236	Drummer wheel flat bracket	\$1.00	_____
237	Drummer wheel spring	\$5.00	_____
238	Sax & Trumpet 1/4" spec. Bolts	\$0.50	_____
239	Sax & Trumpet flat bar 2 req.	\$3.00	_____

Continued on next page

# Chicago Coin's Band Box®

## Reproduction Parts List

[BACK HOME](#)

Item #	Mech. Parts Descriptions Cont.	Price EA	Quantity
240	Sax & Trumpet rocker bar	\$10.00	_____
241	Base rocker wheel bracket	\$10.00	_____
242	Cross bar Mounting bolt	\$3.00	_____
243	Cross bar	\$5.00	_____
244	Base player head cam	\$5.00	_____
245	Violin arm cam	\$5.00	_____
246	Drummer rod cam	\$5.00	_____
247	Base bow cam	\$5.00	_____
248	Piano Player head cam	\$5.00	_____
249	Singer cam	\$3.00	_____
250	Trombone seat bracket assy.	\$15.00	_____
251	Drummer support bracket assy.	\$10.00	_____
252	Motor grommets & inserts	\$10.00	_____
253	1/8" collar	\$2.00	_____
254	5/16" collar	\$2.00	_____
255			_____
256			_____
257			_____
258	Other Mech parts	CALL	_____
259			_____
260			_____
261			_____
262			_____
263			_____
264			_____
265			_____
266			_____
267			_____
268			_____
269			_____
270			_____
271			_____
272			_____
273			_____
274			_____
275			_____
276			_____
277			_____
278			_____
279			_____
280			_____

# Chicago Coin's Band Box®

## Reproduction Parts List

[BACK HOME](#)

Item #	Electrical Parts Descriptions	Price EA	Quantity
300	Drapery motor	\$100.00	_____
301	Mech. motor	\$100.00	_____
302	60 W lamp socket W/bracket	\$6.00	_____
303	15 W florescent lamp	\$8.00	_____
304	Florescent ballast	\$10.00	_____
305	Florescent starter	\$3.00	_____
306	Florescent starter socket	\$10.00	_____
307	Florescent lamp tombstone	\$3.00	_____
308	24 Volt transformer	\$20.00	_____
309	24 Volt relay	\$20.00	_____
310	24 Volt relay base	\$10.00	_____
311	1/4" fuse holder	\$3.00	_____
312	In line drapery switch	\$4.00	_____
313	8 pin socket	\$5.00	_____
314	8 pin plug	\$5.00	_____
315	Wurlitzer 24 play switch assy.	\$75.00	_____
316	10" speaker 35 Watt	\$50.00	_____
317	DPDT drapery switch	\$35.00	_____
318	SPDT drapery switch	\$20.00	_____
319			_____
320			_____
321			_____
322			_____
323			_____
324			_____
325			_____
326			_____
327			_____
328			_____
329			_____
330			_____
331			_____
332			_____
333			_____
334			_____
335			_____
336			_____
337			_____
338			_____
339			_____
331			_____
332			_____
333			_____